

Installing Trough Divider Panels

When installing the Divider Panels, you will need a cordless drill or impact driver & 5/16" socket adapter.

First, attach the Divider Panel to the leg with the screw clamps – The hemmed edge goes toward the feeder leg. **Locate the adjusting screws on the inside edge of the legs, close to the Divider Panels. This prevents animals from being injured by the exposed screw heads.**

Install all three screw clamps loosely, to the attach the Divider Panels to the feeder's legs, then slide the Divider Panel up so it is located directly under the Plate connecting the Hopper to the Motor Shaft. Tighten the center screw clamp enough to hold the Divider Panel in place.

Once you have the Divider Panel in place, locate the attachment lip at the Motor Shaft so the Divider Panel makes a straight line from where it is attached to the leg, to the center of the Motor Shaft.

Carefully install one self-tapping screw in the middle hole of each of the Divider Panels to anchor them in the correct position on the Motor Shaft.

**** Be careful not to over-tighten the self-tapping screws & cause them to strip out the metal in the Motor Shaft.**

When all Divider Panels are in place around the Motor Shaft, tighten the screw clamps at the legs. Each Panel will act as a "Brace" when you insert the self-tapping screws in the opposite Divider Panel.

**** Be careful not to over-tighten the screw clamps & cause them to strip out.**

Finish by inserting the remaining self-tapping screws in the Divider Panels.